

DATA

Formula below for calculating application

Total litres/ha required x speed (km/hr) x width of planter (M) = litres/min /distributer head

(600 x number of distributer heads)

NOZZLE ID	COLOUR	1bar	1.5 bar	2 bar	2.5 bar	3 bar
		14.5 psi	21.8 psi	29 psi	36.3 psi	43.5 psi
		L Water/Min	L Water/Min	L Water/Min	L Water/Min	L Water/Min
CT1590	Blue	1.62	1.98	2.28	2.52	2.76
CT1980	Beige	2.40	2.94	3.42	3.84	4.20
CT2380	Gold	3.60	4.20	4.80	5.40	6.00
CT3180	Lavender	6.00	7.80	9.00	9.60	10.80